



Sanotex® Wipes

Environmental Surface Wipes, compatible with your preferred chemistry

These low-linting, disposable microdenier wipes pull from a reusable dispenser with a spring loaded lid to offer quick, reliable, cost-effective cleaning. Constructed of ultrafine meltblown fibers with a core of stronger spun-bonded fibers for optimal strength, Sanotex are compatible with peroxides, peroxide/peroxyacetic acid, phenolics, and quaternary ammonium-based formulations, and deliver chemicals to surfaces efficiently.

FEATURES

- Cost-effective, 100% synthetic, and disposable
- Self-closing, spring-loaded lid keeps wipes wet longer
- Measured chemical usage and flexible chemical choice
- Compatible with bleach, quat, and peroxide-based disinfectants

Contec part no.	description	size	packaging
85337	Sanotex Environmental Surface Wipes, half fold	10 x 12" (25 x 30cm)	60/roll, 30 rolls/case
85338	Sanotex Environmental Surface Wipes, half fold	10 x 12" (25 x 30cm)	40/roll; 8 rolls/case
85339	Sanotex Environmental Surface Wipes	6" x 8" (15 x 20cm)	150/roll; 6 rolls/case
85340	Sanotex Environmental Surface Wipes, half fold	10 x 12" (25 x 30cm)	60/roll; 6 rolls/case
85347	Sanotex Environmental Surface Wipes, half fold	10 x 12" (25 x 30cm)	40/roll; 48 rolls/case
85357	Sanotex Environmental Surface Wipes	6" x 8" (15 x 20cm)	150/roll; 30 rolls/case
85341	Sanotex self-closing dispensing canister, empty, reusable	4.75 x 8" (12 x 20cm)	6/case



How to use Sanotex® Wipes

< Insert a dry roll of Sanotex® wipes into the canister.



< Carefully pour chemical solution over center of wipe roll in canister. Allow five minutes before use to assure proper saturation of wipes.



< From the center of the roll, pull a wipe up and carefully thread through opening in canister lid (approximately one inch). Replace lid, screwing on tightly.



< To dispense, open the hinged lid and pull the wipe through the opening at an angle. The spring-loaded lid will re-close automatically.

 **CONTEC**[®]
PROFESSIONAL

ContecProfessional.com